


# Enterprise with TDM-PBX



- Enterprise with TDM-PBX, connect WG-2608/35xx FXS port to TRUNK port of TDM-PBX, **keep using TDM-PBX and evolve into IP communication.**
- **IP-to-Extension / IP-to-PSTN:** The call from IP through WG-2608/35xx to TDM-PBX, than outgoing to extension or PSTN.
- **Extension-to-IP:** All extensions could make call through WG-2608/35xx to remote branch or client over internet(IP).
- **PSTN-to-IP:** Home work could make call from PSTN to TDM-PBX, than go through WG-2608/35xx to remote branch or client.