

* How to configure P2P mode for LP305:

Note:

P2P mode configuration, it was just supported to configure it from **WEB management** and **Telnet command line**.

* WEB management:

- 1) Set your LP305 SIP Configuration in P2P mode

The screenshot displays the 'SIP Protocol Configuration' window in a web management interface. The window has a title bar with 'VOICE YOUR NET' and two tabs: 'SIP Protocol Configuration' (selected) and 'SIP Protocol Advanced Configuration'. A left sidebar contains a navigation menu with items like 'Installation Wizard', 'Advanced Configuration', 'Network Configuration', 'SIP Configuration', 'System Configuration', 'Number Configuration', 'Media Configuration', 'Device Management', 'System Status', and 'Reboot'. The main configuration area includes the following fields:

- Line #:** A dropdown menu set to '2'. A red callout box with an arrow points to it, containing the text: "1. Choose which Line to set up P2P mode."
- Operation Mode:** Two radio buttons: 'SIP Proxy Mode' (unselected) and 'Peer-to-Peer Mode' (selected). A red callout box with an arrow points to the 'Peer-to-Peer Mode' radio button, containing the text: "2. Set on P2P mode".
- Primary Proxy Address:** An empty text field. To its right, 'Port: 5060' is displayed.
- Secondary Proxy Address:** An empty text field. To its right, 'Port: 5060' is displayed.
- Phone Number:** A text field containing '65600'. A red callout box with an arrow points to it, containing the text: "3. Set your LP305 L2 number".
- Registration ID:** An empty text field.
- Registration Password:** An empty text field.
- Display Name:** A text field containing 'P2P 65600'. A red callout box with an arrow points to it, containing the text: "4. Set your display name".
- Expire Time:** A text field containing '60' followed by the label 'Seconds'.
- RTP Port:** A text field containing '26384'.

At the bottom of the configuration area, there are two buttons: 'OK' and 'CANCEL'.

2) Set your LP305 Phone Book Configuration. (It supports 90 data)

1. Press this item

Contacts				
Index	Name	Number	IP Address	Port
01	Jason	79801	192.168.1.1	5060

New Contact

Index	Name	Number	IP Address	Port
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

2. Input the other side Username (You can define it yourself)

3. Input the other side Line number

4. Input the other side IP

5. Input the other side SIP Local UDP Port

Then Reboot it, the L2 of LP305 will work in P2P mode.

=====

*Telnet command line:

When you access it from Telnet command line or consol line.

You can use those "command", below:

1) Sip configuration: sip -line2 mode 0 number 65600 display P2P6500
(0/1: P2P/PX)

2) Phone book configuration: pbook -add name Jason number 79801 ip 192.168.1.1 port 5060

Then "commit" and "reboot" it, it will re-start system. The line 2 of LP305 will work in P2P mode.

=====